

BASIC CODES:

CODE = RIVETNAME

CODE = RIVETNAME

CODE = RIVETNAME

CODE = RIVETNAME

+ ( INSTALL NEW RIVET

- | EXISTING RIVET

CODE = RIVETNAME

CODE = RIVETNAME


REMOVE/REPLACE RIVET

- (01) RAPPEL STEP INSTALLATION LHS (SHOWN)
- (02) RAPPEL STEP INSTALLATION RHS (OPPOSITE)

NOTES 1 PRESS FIT BUSHING INTO PLATE. 2. INSTALL ITEM 09 AND 10 WITH LOCTITE 2440.

TORQUE VALUE CHART (DRY) FOR ALL FASTENERS UNLESS OTHERWISE SPECIFIED FASTENER RECOMMENDED STANDARD TORQUE DIAMERTER/THREAD RANGE SIZE 10 - 32 15 TO 20 IN-LB 30 TO 40 IN-LB 1/4 - 28 NOTE: THE ABOVE VALUES APPLY TO ANY FASTENER COMBINATION UNLESS OTHERWISE SPECIFIED. TARE

TORQUE MUST BE ADDED TO ALL TORQUE VALUES.



TOLERANCES ON:

ANGLES

NOT TO SCALE

SHEET 1 OF 1

DECIMALS

 $X.XXX \pm 0.010$ 

 $x.xx \pm 0.03$ 

 $\times . \times \pm 0.1$ 

RAPPEL STEP

ASSEMBLY